




Aerodrome Ground Signals



When displayed at a PLA, a red and white cone with the point of the cone pointing into wind indicates that the dropping area is active.




When displayed at an unattended aerodrome (other than an aerodrome intended to be used solely for agricultural operations) or an aerodrome where an aerodrome FIS is in operation, a white letter "A" indicates that agricultural operations or agricultural training operations are being conducted. Such flights may not be complying with the direction of the aerodrome circuit.



When displayed at an aerodrome, an arrow formed of white fabric strips on the surface indicates that:

- (a) Gliding is in progress.
- (b) Gliders are landing and being towed off in the direction of the arrow.
- (c) Tow lines are likely to be on the ground at any distance from the towing source and on or parallel to the signal strips.



White crosses displayed horizontally on the manoeuvring area indicate that the ground on which they are displayed is unfit for use. White crosses displayed at each extremity of a runway or portion of a runway indicate that the runway or portion of the runway is unfit for use.