

Unusual Attitudes

INSTRUMENT FLYING

Objective

To recognise, and recover to straight and level from a nose-high or nose-low unusual attitude.

1. Considerations

- Unusual attitude can be entered due high workload, fixation, leans
- Trust the instruments
- Recover to straight and level first
- Then regain altitude and heading
- Change – check – hold – adjust – trim
- Must identify the position of the horizon

Limited Panel



1. Check airspeed—stop further increase or decrease
2. Adjust power to compensate
3. Roll wings level

Change If altitude ↑ – ↓ backpressure (push)
If altitude ↓ – ↑ backpressure (pull)
Until 100s pointer stops moving

Check

Hold

Adjust

Trim (but you shouldn't need to)

2. Airmanship

- Enough height for recovery
- SRS–A/S, Alt, then the rest
- Limiting speeds— V_A , V_{NG} , V_{NE} , and rpm limit

3. Aeroplane Management

- Smooth positive control movements

4. Human Factors

- Human orientation system has limitations
- Instrument failure rare
- Trust the instruments

5. Air Exercise

- Smooth control movements whenever speed above V_A

Attitude	Recognition	Recovery
Nose High	<ul style="list-style-type: none"> • Low or ↓ airspeed • ↑ altitude • ↑ rate of climb • ↓ engine RPM 	<ul style="list-style-type: none"> • Full power and level wings • Push forward on c/c until airspeed/altimeter stops • Check • Hold • At normal cruise speed reduce power • Adjust • Trim
Nose Low	<ul style="list-style-type: none"> • High or ↑ airspeed • ↓ altitude • ↑ rate of descent • ↑ engine RPM 	<ul style="list-style-type: none"> • ↓ power and level wings • Ease out of dive, check airspeed • When altimeter stops • Check • Set cruise power • Hold • Adjust • Trim
Spiral Dive	<ul style="list-style-type: none"> • High or ↑ airspeed • ↓ altitude • High angle of bank • High rate of descent • High or ↑ G-loads • ↑ engine RPM 	<ul style="list-style-type: none"> • Close throttle and level wings • Ease out of dive, check airspeed • When altimeter stops • Check • Set cruise power • Hold • Adjust • Trim

- When straight and level regained, return to original reference altitude and heading